

DMX Channels				
Small	Standard	Channel Name	DMX Value	Function
1	1	Color	0-4	White
			5-8	White+Color1
			9-12	Color1
			13-17	Color1+2
			18-21	Color2
			22-25	Color2+3
			26-29	Color3
			30-34	Color3+4
			35-38	Color4
			39-42	Color4+5
			43-46	Color5
			47-51	Color5+6
			52-55	Color6
			56-59	Color6+7
			60-63	Color7
			64-68	Color7+8
			69-72	Color8
			73-76	Color8+9
			77-81	Color9
			82-85	Color9+10
			86-89	Color10
			90-93	Color10+11
			94-98	Color11
			99-102	Color11+12
			103-106	Color12
			107-110	Color12+13
			111-115	Color13
			116-119	Color13+14
			120-123	Color14
			124-127	Color14+White
			128-191	CCW Color strem
			192-255	CW Color strem
2	2	Strobe	0-3	Closed
			4-103	Strobe Fast->Slow
			104-107	Open
			108-207	Strobe Fast->Slow
			208-212	Open
			213-251	Random Strobe
			252-255	Open
3	3	Dimming	0-255	0-100% linear dimming
4	4	Gobo	0-3	White
			4-7	Gobo1
			8-11	Gobo2

4	4	Gobo	12-15	Gobo3
			16-19	Gobo4
			20-23	Gobo5
			24-27	Gobo6
			28-31	Gobo7
			32-35	Gobo8
			36-39	Gobo9
			40-43	Gobo10
			44-47	Gobo11
			48-51	Gobo12
			52-55	Gobo13
			56-59	Gobo14
			60-63	Gobo15
			64-67	Gobo16
			68-71	Gobo17
			72-113	CCW Gobo stream
			114-117	White
			118-159	CW Gobo Stream
			160-166	Gobo1 Shake
			117-172	Gobo2 Shake
			173-179	Gobo3 Shake
			180-185	Gobo4 Shake
			186-191	Gobo5 Shake
			192-198	Gobo6 Shake
			199-204	Gobo7 Shake
			205-211	Gobo8 Shake
			212-217	Gobo9 Shake
			218-223	Gobo10 Shake
			224-230	Gobo11 Shake
			231-236	Gobo12 Shake
			237-243	Gobo13 Shake
			244-249	Gobo14 Shake
			250-255	Gobo15 Shake
5	5	Prisms	0-63	White
			64-127	Prism1
			128-191	Prism2
			192-255	Prism1+Prism2
6	6	Prism Rotating	0-127	Prism position
			128-190	CW Prism Rotate Fast->Slow
			191-192	Stop
			193-255	CCW Prism Rotate Slow->Fast
7	7	Macro	0-255	Buit-in Macro
8	8	Frost	0-255	Linear 0-100% frost
9	9	Focus	0-255	0-100% Focus
10	10	Pan	0-255	Pan
11	11	Pan Fine	0-255	Pan Fine
12	12	Tilt	0-255	Tilt

13	13	Tilt Fine	0-255	Tilt Fine
14	14	P/T Speed	0-255	Pan and Tilt Speed
15	15	Reset	255	Total Reset
16	16	Lamp	63-65	Lamp off
			178-180	Lamp On
	17	Reserve	0-255	Reserve
	18	Color Wheel Speed	0-255	Color Wheel Speed fast->slow
	19	Gobo Wheel Speed	0-255	Gobo Wheel Speed fast->slow
	20	Reserve	0-255	Reserve